

TOREBO → FALKENBERG GODSSTATION		
Torebo – Falkenberg godsstation Enkelspår. System H. ATC (Fjtkl G).		
Km	Sth	Signaler, trafikplatser, mm
101+836	190/200	Infsi (21 och 51) <u>Torebo (Teo)</u> Hatavla Ublsi (Teo L 1) Driftplatsgräns
102+405	Enl hsi	
102+836	105	
102+956		
103+136		
103+975		Vsi, 21961, Lisbro
105+103		Vsi, 21962, Stafsinge
106+301		Vsi, 21967, Lindeskog (Stafsingev)

Teo → Fabg

Km	Sth	Signaler, trafikplatser, mm
107+172	105	Infsi (21)
107+533	40	Hatavla
107+648		Vsi, 21970, Kvekatorpsvägen
108+167		<u>Falkenberg godsstation (Fabg)</u>
108+327- 108+366		Msi (35 <1>, 31 <2>, 33 <3>)