

STOCKHOLM C → VÄSTERÅS NORRA

Lutningsförhållande max 12,5 ‰

Stockholm C

Stockholm driftplats

System H. ATC (Fjtkl Cst)

För gång Cst – Ke – Tm, se linjebeskrivning Cst – Udl

Km	Sth	Signaler, tpl m.m.
0+000	Enl. Hsi	<u>Stockholm C (Cst) *</u>
0+000- 0+120		Msi (354<19>, 356<18>, 358<17>, 360<16>, 362<15>, 364<14>, 366<13>, 368<12>, 370<11>, 372<19>)
0+160	30	Hatavla, bangårdförhållanden<10-19>
0+185- 0+198		Msi (374<19>, 376<18>)
0+200- 0+380		Msi (378<17>, 380<16>, 382<15>, 384<14>, 386<13>, 388<12>, 390<11>, 392<8>, 434<8>) Bromsprovsignal <1 – 7, 10 – 19> A-signal <1 – 7, 10 – 19>
0+450- 0+590		Msi (496<7>, 498<6>, 500<5>, 502<4>, 504<3>, 506<2>, 508<1>, 426<U3>, 430<N3>, 522<U1>)
Stockholm C forts nästa sida		

Cst → Vån

Km	Sth	Signaler, tpl m.m.
	30	Stockholm C forts från föregående sida
0+520	80	Hatavla <N3, U3>
0+550- 0+553		Msi (668<E7>, 670<E6>, 518<E2>)
0+822	70b)	Hatavla <U1, N1, A1> b) sth 50 <C1>
0+700- 0+875		Msi (696<A4>, 444<E7>, 446<E6>, 418<U4>, 584<U3>, 586<N3>, 560<E4>, 524<E3>, 456<C1>, 564<U1>, 568<N1>, 570<A1>)
0+935		Msi (402<C6>, 414<U4>)
1+075		Tunnel, Centraltunneln 218 meter <U3>, <N3>
1+060		Norra Bantorget (Nbt) hst
1+100- 1+305		Msi (640<U3>, 642<N3>, 574<U4>, 578<C4>, 580<C3>, 582<C2>, 566<C1>, 608<U1>, 592<N1>, 598<A1>)
1+247	40	Hatavla <C4, C3, C2>
1+400- 1+572		Msi (616<U1>, 618<A3>, 594<N1>, 624<A1>)
1+685		Gräns mellan driftplatsdelar

Km	Sth				Signaler, tpl m.m.
Karlberg Stockholm driftplats System H. ATC (Fjtkl Cst) (Riktning Stockholm C – Solna)					
	U1	U3	N3	N1	
	70	80	80	70	
1+685- 1+695	x	x	x	x	Msi (110, 114, 120, 124)
1+700	80	—	—	80	Hatavla
1+985- 2+053	x	x	x	x	Msi (112, 116, 122, 126)
2+100	x	x	x	x	<u>Karlberg (Ke) *</u>
2+140	100/ 125	100	100	100	Hatavla
2+280	x	x	x	x	Msi (150, 152, 154, 156) Till Nst
2+454- 2+492	x	x	x	x	Msi (174, 176, 182, 184)
2+700	120/ 140	—	—	—	Hatavla

Cst → Vån

Km	Sth						Signaler, tpl m.m.
	U1	U3	U2	N2	N3	N1	
	120/	100	90	90	100	100	
	140						
2+820	x	x	—	—	x	x	Gräns mellan driftplatsdelar
3+142	x	x	—	—	—	—	Msi (194, 196)
3+265	—	—	—	—	x	x	Msi (214, 216)
3+280	160/	—	—	—	—	—	Hatavla
	180						
	U1	U5	U2	N2	N5	N1	
	160/	100	90	90	100	100	
	180						
3+375	—	—	x	x	—	—	Strömbegränsnings- tavla
3+380- 3+410	—	—	120	120	—	115/ 130	Hatavla
							Tomteboda övre forts. nästa sida

Km	Sth						Signaler, tpl m.m.
	U1	U5	U2	N2	N5	N1	Tomteboda övre forts. från föregående sida
	160/	100	90	90	100	100	
	180						
3+590	x	x	x	x	x	x	<u>Tomteboda övre</u> <u>(Tmö) *</u>
3+625- 3+665	—	—	—	x	x	x	Msi (234, 238, 242)
3+861- 3+883	x	x	x	—	—	—	Msi (224, 228, 232)
4+045	—	—	—	130/	—	—	Hatavla
	U1		U2	N2		N1	
	160/		120	130/		115/	
	180			140		130	
4+150	—		—	—		160/	Hatavla
						200	
4+210	—		130/	—		—	Hatavla
			140				

Km	Sth				Signaler, tpl m.m.
Karlberg – Sundbyberg Stockholm driftplats. System H. ATC. (Fjtkl Cst). (Riktning Stockholm C – Huvudsta)					
	U1	U3	N3	N1	
	70	80	80	70	
1+685- 1+694	x	x	x	x	Msi (110, 114, 120, 124)
1+700	80	—	—	80	Hatavla
1+985- 2+053	x	x	x	x	Msi (112, 116, 122, 126)
2+100					<u>Karlberg (Ke) *</u>
2+140	100/ 125	100	100	100	Hatavla
2+280	x	x	x	x	Msi (150, 152, 154, 156) Till Nst
2+454- 2+492	x	x	x	x	Msi (174, 176, 182, 184)
2+700	120/ 140	—	—	—	Hatavla

Km	Sth						Signaler, tpl m.m.
	U1 100/ 125	U3 100	U2 90	N2 90	N3 100	N1 100	
2+820	x	x	—	—	x	x	Gräns mellan driftplatsdelar
3+142	x	x	—	—	—	—	Msi (194, 196)
3+265	—	—	—	—	x	x	Msi (214, 216)
	U3 100	U4 100	N4 100		N3 100		
3+375	—	x	—		—		Strömbegränsningstavla
3+410	—	—	x		—		Strömbegränsningstavla
3+590	x	x	x		x		<u>Tomteboda övre</u> <u>(Tmö)*</u>
3+840- 3+900	—	90	90		90		Hatavla
4+100	90	—	—		—		Hatavla
4+097- 4+180	x	x	x		x		Msi (300, 302, 304, 306) Gräns mellan driftplatsdelar

Km	Sth	Signaler, tpl m.m.
4+649	90	<u>Huvudsta (Huv) *</u>
4+649		Vsi, 31260 Järnvägsgatan
4+792		Msi (334 <2=U>, 336 <3=N>)
4+896	130	Gräns mellan driftplatsdelar
4+881		Detektor, strömvtagare
4+1101 =5+000		Längdmättningsjustering (101 m)
5+328		Msi (894<2>, 896<3>)
5+735		Msi (932<2>, 934<3>)
6+173		Msi (954<2>, 956<3>)
6+394		<u>Sundbyberg (Sub) *</u>
6+527		Msi (960<2>, 962<3>)
6+797		Msi (976<2>, 978<3>)
6+809		Vsi, 31268 Esplanaden
7+615		Hatavla
7+730		Ublsi (Sub U42, N72)
7+843		Driftplatsgräns

Km	Sth	Signaler, tpl m.m.
(Sundbyberg) – (Spånga) Dubbelspår. System H. ATC (Fjtkl Cst)		
	130	
8+600		Infsi (22, 52)
8+785		Vsi, 31271 Sulkyvägen
8+913		<u>Duvbo (Duo)</u>
9+265		Ublsi (Duo U42, N72)
9+394	130	Hatavla. Driftplatsgräns
10+135		Vsi, 31273 Fristadsvägen
Spånga – Kallhäll Flerspår. System H. ATC (Fjtkl Cst)		
10+420	x x	Infsi (104 <U>, 106 <N>)
	1U 2U 2N 1N	
11+104	160/ 130/ 130/ 160/ 200 160 160 200	Hatavla <4, 3, 2, 1>
11+188- 11+238	x x x x	Msi (142 <4>, 144 <3>, 146 <2>, 148 <1>)
11+415		<u>Spånga (Spå) *</u>
11+588	x — — x	Msi (154 <3>, 156 <2>)
12+202	x x x x	Ublsi (202 <4>, 204 <3>, 206 <2>, 208 <1>)

Cst → Vån

Km	Sth				Signaler, tpl m.m.
	1U 160/ 200	2U 130/ 160	2N 130/ 160	1N 160/ 200	
13+076	x	x	x	x	Mblsi (Spå 1U4, 2U4, 2N4, 1N4)
13+490	160/ 200	—	—	160/ 200	Hatavla
13+899- 13+894	x	x	x	x	Infsi (22 <4>, 24 <3>, 54 <2>, 52 <1>)
14+312	—	x	x	—	Msi (28, 58)
14+351	160/ 200	—	—	160/ 200	Hatavla
14+489					<u>Barkarby (Bkb)</u>
14+659	—	x	x	—	Msi (34, 64)
14+824	x	—	—	x	Msi (32, 62)
15+289	x	x	x	x	Ublsi (Bkb 1U42, 2U44, 2N74, 1N72)
15+391- 15+393	x	x	x	x	Driftplatsgräns
(Barkarby) – (Kallhäll) Flerspår, System H. ATC (Fjtkl Cst)					
16+037	110/1 40	110/ 140	110/ 140	110/1 40	Hatavla
16+090	x	x	x	x	Mblsi (Bkb 1U4, 2U4, 2N4, 1N4)

Km	Sth				Signaler, tpl m.m.
	1U	2U	2N	1N	
	110/	110/	110/	110/	
	140	140	140	140	
16+890- 16+908	x	x	x	x	Infsi (22, 24, 54, 52)
17+034	130/ 160	—	—	130/ 160	Hatavla
17+312- 17+313	—	x	x	—	Msi (28, 58)
17+494					<u>Jakobsberg (Jkb) *</u>
17+638	—	x	x	—	Msi (34, 64)
17+751	—	—	160/ 180	160/ 200	Hatavla
17+897	160/ 200	—	—	—	Hatavla
17+962	—	160/ 180	—	—	Hatavla
18+250	—	—	—	—	Msi (92<M>)
18+478	x	x	x	x	Ublsi (Jkb 1U42, 2U44, 2N74, 1N72)
18+591	x	x	x	x	Driftplatsgräns
19+322- 19+324	x	x	x	x	Mblsi (Jkb 1U4, 2U4, 2N4, 1N4)
19+784	—	135	140/ 160	—	Hatavla

Cst → Vån

Km	Sth				Signaler, tpl m.m.
	1U	2U	2N	1N	
	160/ 200	135	140/ 160	160/ 200	
20+204- 20+207	x	x	x	x	Infsi (22, 24, 54, 52)
20+447	—	—	—	—	Msi (30<M>)
20+632	x	x	x	x	Nedkopplingstavla
20+786- 20+794	—	x	x	—	Msi (28, 58)
20+786	—	—	—	—	Nedkopplingstavla <3, 4>
20+870	—	100	—	—	Hatavla
21+010	—	—	130	—	Hatavla
Kallhäll forts nästa sida					

Km	Sth				Signaler, tpl m.m.
	1U	2U	2N	1N	Kallhäll forts från föregående sida
	160/ 200	100	140/ 160	160/ 200	
21+030					<u>Kallhäll (Khä) *</u>
21+049- 21+086	x	—	—	x	Msi (32, 62)
21+157	—	—	—	—	Tågfärdvägs slutpunkt stoppbock <4, 3>
21+173- 21+176	—	x	x	—	Msi (34, 64)
21+250	—	—	160/ 200	—	Hatavla
21+300	—	160/ 200	—	—	Hatavla
		U	N		
		160/ 200	160/ 200		
21+639- 21+648		x	x		Msi (40, 70)
21+846		x	x		Tunnel, Båghustunneln 574 m
22+480		x	x		Ublsi (Khä U42, N72)
22+580		x	x		Driftplatsgräns

Cst → Vån

Km	Sth	Signaler, tpl m.m.
(Kallhäll) – (Bro Nygård) Dubbelspår, System H. ATC (Fjtkl Cst)		
	160/200	
22+849		Tunnel, Trappeberg 180 meter
23+209		Tunnel, Stäket 429 meter
23+547		Mblsi (Khä U4, N4)
24+031		Tunnel, Stäksund 132 meter
24+421		Tunnel, Dalkarlstunneln 163 meter

Km	Sth	Signaler, tpl m.m.
24+585	160/200	Infsi (22, 52)
24+887	130/160	Hatavla
25+089		Tunnel, Svartvik 537 meter
25+500- 25+502		Msi (28<4>, 58<1>)
26+087	100	Hatavla <2, 3>
26+242		<u>Kungsängen (Kän) *</u>
26+350		Msi (64<2>)
26+375		Msi (62<1>)
26+387		Msi (34<3>, 32<4>)
26+531	130/160	Hatavla <1>
26+539	130/160	Hatavla <4>
26+781		Tågfärdvägs slutpunkt stoppbock <13>
26+834- 26+883		Msi (36<3>, 66<1>)
27+157	200	Hatavla
27+622		Ublsi (Kän U42, N72)
27+731		Driftplatsgräns
28+634		Mblsi (Kän U4, N4)
29+988		Mblsi (Kän U6, N6)
30+222= 32+000		Längdmättningsjustering (1778m)

Cst → Vån

Km	Sth	Signaler, tpl m.m.
Bro Nygård – Bro Bro driftplats System H. ATC (Fjtkl Cst)		
32+950	200	Infsi (222, 252)
33+600		<u>Bro Nygård (Brny) *</u>
34+091		Msi (242<3>, 272<5>)
34+060	50	Hatavla <SL-depå>
34+107		Msi (284<SL-depå>)
34+294		Gräns mellan driftplatsdelar
35+113		Msi (322<1>, 352<2>)
35+270		ATC börjar (<SL-depå/KF-spår>)
35+298		Msi (386<SL-depå/KF-spår>)
35+331		Msi (382<4>)
36+099- 36+201		Msi (332<3>, 384<4>, 362<5>)
36+387		<u>Bro (Bro) *</u>
37+058		Ubsi (U342, N372)
37+233		Driftplatsgräns

Km	Sth	Signaler, tpl m.m.
(Bro) – (Västerås C) Dubbelspår. System H. ATC (Fjtkl Cst)		
39+146	200	Infsi (222, 252)
39+846= 40+000		Längdmättningsjustering (154 m)
40+349		Msi (224<2>, 254<1>)
40+688		<u>Toresta (Tot)</u>
41+830		Ublsi (Tot U242, N272)
41+950		Driftplatsgräns
42+361		Tunnel, Håbotunneln 411 meter
42+971		Mblsi (Tot U4, N4)
44+016		Infsi (22, 52)
44+657		Msi (24<1>)
44+605		Msi (56<2>)
45+114		Msi (80<3>)
45+240		Tågfärdvägs slutpunkt stoppbock <3>
45+421		<u>Bålsta (Bål) *</u>
45+625		Msi (32<1>, 62<2>)
47+965		Ublsi (Bål U42, N72)
48+090		Driftplatsgräns

Cst → Vån

Km	Sth		Signaler, tpl m.m.
	U	N	
	200	200	
48+417			Nedkopplingstavla
50+086	x	x	Mblsi (Bål U4, N4)
52+338	x	x	Mblsi (Bål U6, N6)
54+677	x	x	Infsi (22, 52)
55+703	x	x	Msi (24, 54)
55+801	160	—	Hatavla
56+018			<u>Ekolsund (Eko)</u>
56+915- 58+000			Längdmättningsjustering (1085m)
58+349	x	x	Ublsi (Eko U42, N72)
58+459			Driftplatsgräns
59+490			Detektor, varmgång/tjuvbroms
60+978	x	x	Mblsi (Eko U4, N4)
61+500	200	—	Hatavla
63+708	x	x	Infsi (22, 52)
64+695	x	x	Msi (24<1>, 54<2>)
65+000			<u>Grillby (Gib)</u>
66+193	x	x	Ublsi (Gib U42, N72)
66+315			Driftplatsgräns

Km	Sth		Signaler, tpl m.m.
	U	N	
	200	200	
68+073			Mblsi (Gib U4, N4)
69+932			Mblsi (Gib U6, N6)
71+766			Infsi (22, 52)
72+755			Msi (24<1>, 54<2>)
73+382			<u>Enköping (Ep) *</u>
73+555			Msi (26<1>)
73+560			Plattformsövergång med automatiska bommar <1>
73+675- 73+756			Msi (62<2>, 64<3>)
73+896			Msi (32<1>)
73+975	—	160/ 180	Hatavla
74+269			Ublsi (Ep U42, N72)
74+285	—	200	Hatavla
74+450			Driftplatsgräns

Cst → Vån

Km	Sth	Signaler, tpl m.m.
76+645	200	Mblsi (Ep U4, N4)
76+994		Tunnel, Ullbro 321 meter
78+787= 79+000		Längdmättningsjustering (213m)
79+302		Mblsi (Ep U6, N6)
81+617		Infsi (22, 52)
82+442		Msi (24, 54)
82+528		Msi (34<Bv-stick>)
82+796		<u>Lundby (Lub) *</u>
84+282		Ublsi (Lub U42, N72)
84+409		Driftplatsgräns
86+897		Mblsi (Lub U4, N4)
89+568		Mblsi (Lub U6, N6)
92+335		Infsi (22, 52)
94+381		Msi (24, 54)
94+724		<u>Tortuna (Ttu) *</u>
95+078		Ublsi (Ttu U42)
95+083		Ublsi (Ttu N72)
95+213		Driftplatsgräns

Km	Sth	Signaler, tpl m.m.
97+617	200	Mblsi (Ttu U4, N4)
100+382		Mblsi (Ttu U6, N6)
102+122=		Längdmättningsjustering (2878m)
105+000		
105+056		Nedkopplingstavla

Reservsida