

FALKENBERG GODSSTATION → TOREBO		
Falkenberg godsstation – Torebo		
Enkelspår. System H. ATC (Fjtkl G).		
Km	Sth	Signaler, trafikplatser, mm
108+167	40	<u>Falkenberg godsstation (Fabg)</u>
107+955		Msi (32 <2>, 36 <1>)
107+668		Msi (34 <3>, 38 <2>)
107+648		Vsi, 21970, Kvekatorpsvägen
107+533		Hatavla
107+172	105	Ublsi (Fabg L 2)
106+301		Vsi, 21967, Lindeskog (Stafsingev)
105+103		Vsi, 21962, Stafsinge
103+953		Vsi, 21961, Lisbro

Fabg → Teo

Km	Sth	Signaler, trafikplatser, mm
	105	
103+136	Enl hsi	Infsi (12)
102+836	190/200	Hatavla
102+405		<u>Torebo (Teo)</u>
102+015		Ublsi (Teo U 2 och N 2)
101+836		Driftplatsgräns